


MiniLink® Mesh Configuration Note #2

Example Configuration Settings for IP Camera and Node to Network Switch/NVR/PC/Laptop



www.microtekelectronics.com | info@microtekelectronics.com

25691 Atlantic Ocean Dr; Ste B-3; Lake Forest, CA 92630

Voice: 888-366-4276 Fax: 949-297-4933

Note: This diagram is conceptual and is for illustration only and assumes an ideal environment for wireless transmission. Due to possible adverse site-specific wireless conditions, MicroTek cannot guarantee operability of the system as depicted in this diagram. A bench test is highly recommended for familiarization and easier troubleshooting should it be necessary. Channel selections and IP Addresses can be preset for convenience if desired, however, environmental restrictions may require reconfiguration to some degree. Technical assistance is available Monday through Friday 8:00 AM to 5:00 PM PST at 888-366-4276 or info@microtekelectronics.com