


## Kit Contents

- 1 x ThruLink3 Unit
- 2 x LTE paddle antenna and 1 x magnetic mount cable antenna
- 1 x Wi-Fi Antenna
- 1 x US Power Plug
- 1 x ThruLink3 User Information with Warranty Card

## Network and Power Connections




## Antenna Connection Note

The primary antenna connection is the LTE Wireless Network Antenna. If an additional LTE magnetic mount antenna is connected to the Aux LTE connector, the two antennas must be placed in positions separated by a minimum of 8 inches (20cm).

## WLAN Connection Note

The WLAN connection is not enabled by default and needs to be configured separately. It is only available when in route mode.

## Wi-Fi Antenna, Indicators, and SIM Card



Only use the Wi-Fi Antenna on the Wi-Fi port.

A SIM card must be installed prior to power up for LTE Network operation. SIM cards are not hot-swappable.

The RED Power indicator will be ON when the unit is powered on.

The 2 x STATUS LEDs will become operational when the Encryption Tunnel is enabled. The second LED will remain pulsing while establishing a connection. Once established, it will turn to a solid state, and the third LED will periodically pulse.

See the User Guide for additional setup details and procedures.